



# T7414C

## STRAP-ON/OUTSIDE TEMPERATURE SENSOR

### PRODUCT DATA



T7414C  
outdoor-mounted



T7414C  
strap-on

### FEATURES

- Pt1000 / NTC20 temperature sensing element
- Small size
- Easy mounting
- Fully encapsulated housing

### SPECIFICATIONS

#### Ambient limits

Operating temperature

- Strap-on -30...+110 °C (-22...+230 °F)

- Outdoor -30...+70 °C (-22...+158 °F)

Transport / storage temp. -30...+70 °C (-22...+158 °F)

Humidity 5...95%rh, non-condensing

#### Safety

Protection standard IP65 as per EN60529

Flame-retardant housing V1 as per UL94

#### Housing

Plastic

#### Dimensions

See page 2

#### Weight

60 g

#### Mounting

Pipe and wall

#### Cable length

approx. 1 m

#### Temperature sensor

Sensing element

Pt1000, NTC20kΩ

#### Sensing range

- Strap-on -30...+110°C (-22...+230°F)

- Outdoor -30...+70°C (-22...+158°F)

#### Response time

- Strap-on Pt1000  $\tau_{0.5} \approx 36$  s

- Strap-on NTC20kΩ  $\tau_{0.5} \approx 45$  s

- Outdoor Pt1000  $\tau_{0.5} \approx 240$  s

- Outdoor NTC20kΩ  $\tau_{0.5} \approx 300$  s

#### Sensitivity

-Pt1000  $\approx 3.85\Omega / K$

-NTC20kΩ 20 kΩ at 25 °C, non-linear

#### Accuracy

- Pt1000 DIN IEC751 Class B

$\Delta T/K = 0.3 + 0.005 \cdot |t|$  ( $t = °C$ )

0,3 K at 25 °C

#### Resistance

-Pt1000 1000Ω at 0 °C

-NTC20kΩ 20kΩ at 25 °C

### GENERAL


The Strap-on Temperature Sensor is used to detect the supply or return water flow temperature on the pipe work.

The Outside Air Temperature Sensor is used in heating, ventilating and air conditioning systems to detect the outside temperature for reset of the main setpoint in weather-dependent control systems.

### MODELS

OS-No.	type / sensing element	mounted using
T7414C1004	strap-on / outdoor / Pt1000	clamp band / screws
T7414C1012	strap-on / outdoor / NTC20	clamp band / screws

## DIMENSIONS



## MOUNTING AND INSTALLATION

### OUTDOOR

The outdoor air temperature sensor should be mounted on the wall of buildings having windows of the main occupancy rooms or on the coldest side (N-NW side).

It should not be subjected to direct sunshine and be mounted on an open facade so that it can detect all weather conditions.

The mounting height should be 2/3 of the way up wall on up to three-story buildings or between the second or third floor on taller buildings.

Avoid mounting the sensor above windows, doors, air extractors or other heat sources, under a balcony, the eaves, or in a wall niche.

The cable conduit through the wall must be sealed to prevent measurement errors by warm air circulation.

Fasten the sensor with the two supplied screws at the selected place on the wall as shown in Fig. 2.




Fig. 2. T7414C outdoor-mounted

### STRAP-ON

The strap-on temperature sensor consists of a sensor housing and a clamp band with an adjustable lock for mounting on pipes up to a diameter of 28 mm.

The sensor is equipped with a 1 m-long two-lead connecting cable.

The strap-on sensor must be mounted onto the water pipe with the clamp band at a minimum distance of 1.5 m from the mixing valve. Avoid mounting the sensor near heat sources, as its measurement could then be influenced by warm air circulation. Fasten the sensor as shown in Fig. 3.




Fig. 3. T7414C strap-on mounted

**Honeywell**

Manufactured for and on behalf of the Environmental and Combustion Controls Division of Honeywell Technologies Sàrl, Ecublens, Route du Bois 37, Switzerland by its Authorized Representative:

#### Automation and Control Solutions

Honeywell GmbH  
Böblinger Straße 17  
D-71101 Schönaich  
Phone: (49) 7031 63701  
Fax: (49) 7031 637493  
<http://ecc.emea.honeywell.com>

Subject to change without notice. Printed in Germany

EN0B-0475GE51 R0907